

Carregador Universal para Notebook 90W – 48418

Conector 3.0*1.0*10mm(19V) - D

Asus	AcerChromebookR11
Asus	C720
Asus	C720P
Asus	C730E
Asus	C738T
Asus	C740
Asus	CB3
Asus	CB5:
Asus	CB3-111-C4HT
Asus	CB3-111-C670
Asus	CB3-111-C6EQ
Asus	CB3-111-C8UB
Asus	CB3-131-C3SZ
Asus	CB3-131-C3VC
Asus	CB5-132T-C1LK
Asus	CB5-132T-C32M
Asus	CB5-132T-C8ZW
Asus	C720-2103
Asus	C720-2420
Asus	C720-2800
Asus	C720-2802
Asus	C720-2827
Asus	C720-2844
Asus	C720-2848
Asus	C720-3404
Asus	C720-3605
Asus	C720-3871
Asus	C720P-2457
Asus	C720P-2600
Asus	C720P-2625
Asus	C720P-2661
Asus	C720P-2666
Asus	C720P-2834
Asus	C738T-C44Z
Asus	C740-C3P1
Asus	C740-C4PE
Asus	AcerChromebook13C810CB5
Asus	C810-T7ZT
Asus	CB5-311-T1UU
Asus	CB5-311-T677

Asus	CB5-311-T7NN
Asus	CB5-311-T9B0
Asus	CB5-311-T9Y2
Asus	CB5-311P-T9AB
Asus	Chromebook14CB3-431
Asus	CB3-431-C5EX
Asus	CB3-431-C5FM
Asus	CB3-431-C5XK
Asus	Chromebook15C910CB3CB5
Asus	C910-3916
Asus	C910-54M1
Asus	C910-C37P
Asus	C910-C453
Asus	CB3-531-C4A5
Asus	CB5-571-362Q
Asus	CB5-571-C09S
Asus	CB5-571-C1DZ
Asus	CB5-571-C4G4
Asus	CB5-571-C4T3
Asus	CB5-571-C5XU
Asus	CB5-571-C6DL
Asus	CB5-571-C9DH
Asus	AcerAspireOneCloudbook1114
Asus	A01-131
Asus	A01-131M
Asus	A01-431
Asus	A01-431M
Asus	A01-131-C620
Asus	A01-131-C7DW
Asus	A01-131-C9PM
Asus	A01-131-C9RK
Asus	A01-431-C3TM
Asus	A01-431-C7F9
Asus	A01-431-C8G8
Asus	AspireS5S7
Asus	S5-371
Asus	S5-391
Asus	S7-191
Asus	S7-391
Asus	S7-392
Asus	S7-393:
Asus	S5-371-52JR
Asus	S5-391-6419
Asus	S5-391-6495

Asus	S5-391-6836
Asus	S5-391-9860
Asus	S5-391-9880
Asus	S7-191-6400
Asus	S7-191-6447
Asus	S7-191-6640
Asus	S7-191-6859
Asus	S7-391-6413
Asus	S7-391-6468
Asus	S7-391-6478
Asus	S7-391-6810
Asus	S7-391-6812
Asus	S7-391-6818
Asus	S7-391-6822
Asus	S7-391-9411
Asus	S7-391-9427
Asus	S7-391-9492
Asus	S7-391-9839
Asus	S7-391-9886
Asus	S7-392-5401
Asus	S7-392-6803
Asus	S7-392-6807
Asus	S7-392-6832
Asus	S7-392-7863
Asus	S7-392-7885
Asus	S7-392-9404
Asus	S7-392-9439
Asus	S7-392-9460
Asus	S7-392-9890
Asus	S7-393-7451
Asus	AspireR1413
Asus	R5-471T
Asus	R7-371T
Asus	R7-372T
Asus	R5-471T-51UN
Asus	R5-471T-52EE
Asus	R5-471T-71W2
Asus	R7-371T-50V5
Asus	R7-371T-50ZE
Asus	R7-371T-59L6
Asus	R7-371T-59ZK
Asus	R7-372T-77LE
Asus	AspireV13
Asus	V3-331

Asus	V3-371
Asus	V3-372T
Asus	V3-331-P0QW
Asus	V3-371-51UJ
Asus	V3-371-56R5
Asus	V3-371-57JZ
Asus	V3-371-596F
Asus	V3-372T-5051
Asus	A315-23-R0LD
Asus	53G-571X
Asus	55G-588G
Samsung	SamsungNotebook9
Samsung	NP900X5N-K01US
Samsung	NP900X5N-L01US
Samsung	NP900X5T-K01US
Samsung	NP900X5T-X01US
Samsung	NP930QAA-K01US
Samsung	SamsungNotebook9Pro
Samsung	NP940X5M-X01US
Samsung	NP940X5M-X02US
Samsung	NP940X5M-X03US
Samsung	NP940X5N-X01US
Samsung	NP900X3N-K01US
Samsung	NP900X3T-K01US
Samsung	NP900X3T-K02US
Samsung	SamsungNT900X5H
Samsung	NT900X5H-K23W
Samsung	K24P
Samsung	K24W
Samsung	K27S
Samsung	K27S/W
Samsung	K27W
Samsung	K28W
Samsung	K33S
Samsung	K33W
Samsung	K34D
Samsung	K34J
Samsung	K34M
Samsung	K38L
Samsung	K38W
Samsung	K39L
Samsung	SamsungNT900X5M
Samsung	NT900X5M-K58
Samsung	K58WS

Samsung	K716
Samsung	K78S
Samsung	KWSE
Samsung	L38S
Samsung	L58S
Samsung	L78S
Samsung	SamsungNT900X5W
Samsung	NT900X5WI
Samsung	NT900X5W-K58S
Samsung	K58WS
Samsung	SamsungNT900X5L
Samsung	NT900X5LI
Samsung	NT900X5L-K24D
Samsung	K24H
Samsung	K24M
Samsung	K24P
Samsung	K24PH
Samsung	K24S
Samsung	K24W
Samsung	K25D
Samsung	K25M
Samsung	K25PS
Samsung	K25S
Samsung	K31G
Samsung	K34D
Samsung	K34S
Samsung	K38L
Samsung	K38PS
Samsung	K38S
Samsung	K38W
Samsung	K39L
Samsung	K39PS
Samsung	K39S
Samsung	K39W
Samsung	K3EO
Samsung	K501C
Samsung	K51G
Samsung	K52G
Samsung	K58
Samsung	K58A
Samsung	K58S
Samsung	K59
Samsung	K59S
Samsung	K701C

Samsung	K702C
Samsung	K716
Samsung	K71G
Samsung	K78S
Samsung	K79S
Samsung	K99
Samsung	KSF
Samsung	KWSE
Samsung	L24P
Samsung	L24S
Samsung	L24W
Samsung	L34D
Samsung	L34J
Samsung	L34M
Samsung	L38L
Samsung	SamsungNT900X5P
Samsung	NT900X5P-KD2WS
Samsung	KD3S
Samsung	KD3WS
Samsung	KD5S
Samsung	KD5WS
Samsung	SamsungNT901X5L
Samsung	NT901X5LI
Samsung	NT901X5L-EXCU1
Samsung	EXCU2
Samsung	K01/C
Samsung	K01/R
Samsung	K02/C
Samsung	K02/R
Samsung	K03/C
Samsung	K03/R
Samsung	K04/C
Samsung	K04/R
Samsung	K05/C
Samsung	K05/R
Samsung	K06/C
Samsung	K06/R
Samsung	K07/C
Samsung	K07/R
Samsung	K08/C
Samsung	K08/R
Samsung	K09/C
Samsung	K09/R
Samsung	K0A/C

Samsung	K0A/R
Samsung	K0B/C
Samsung	K0B/R
Samsung	K0C/C
Samsung	K0C/R
Samsung	K0D/C
Samsung	K0D/R
Samsung	K0E/C
Samsung	K0E/R
Samsung	K0F/C
Samsung	K0G/C
Samsung	K0H/C
Samsung	K0J/C
Samsung	K0K/C
Samsung	K0L/C
Samsung	K0M/C
Samsung	K0N/C
Samsung	K0P/C
Samsung	K0Q/C
Samsung	K0R/C
Samsung	K0S/C
Samsung	K0T/C
Samsung	K0U/C
Samsung	K0V/C
Samsung	K0W/C
Samsung	K0X/C
Samsung	K0Y/C
Samsung	K0Z/C
Samsung	K10/C
Samsung	K11/C
Samsung	K11/R
Samsung	K12/C
Samsung	K12/R
Samsung	K13/C
Samsung	K13/R
Samsung	K14/C
Samsung	K14/R
Samsung	K15/C
Samsung	K15/R
Samsung	K16/C
Samsung	K16/R
Samsung	K17/C
Samsung	K17/R
Samsung	K18/C

Samsung	K19/C
Samsung	K19/R
Samsung	K1C/R
Samsung	K1D/C
Samsung	K1D/R
Samsung	K1E/C
Samsung	K1E/R
Samsung	K1F/C
Samsung	K1F/R
Samsung	K1G/C
Samsung	K1G/R
Samsung	K1H/R
Samsung	K1J/C
Samsung	K1J/R
Samsung	K1K/C
Samsung	K1K/R
Samsung	K1L/C
Samsung	K1L/R
Samsung	K1M/R
Samsung	K1N/R
Samsung	K1P/R
Samsung	K1Q/C
Samsung	K1Q/R
Samsung	K1R/C
Samsung	K1R/R
Samsung	K1S/C
Samsung	K1T/C
Samsung	K1T/R
Samsung	K1U/C
Samsung	K1U/R
Samsung	K1V/C
Samsung	K1V/R
Samsung	K1W/C
Samsung	K1W/R
Samsung	K1X/C
Samsung	K1X/R
Samsung	K1Y/C
Samsung	K1Y/R
Samsung	K1Z/C
Samsung	K1Z/R
Samsung	K20/C
Samsung	K20/R
Samsung	K201A
Samsung	K201C

Samsung	K201S
Samsung	K202A
Samsung	K203A
Samsung	K21/C
Samsung	K21/R
Samsung	K22/C
Samsung	K22/R
Samsung	K23/C
Samsung	K23/R
Samsung	K24/C
Samsung	K24/R
Samsung	K25/C
Samsung	K25/R
Samsung	K26/C
Samsung	K26/R
Samsung	K27/C
Samsung	K27/R
Samsung	K28/C
Samsung	K28/R
Samsung	K29/C
Samsung	K2A/C
Samsung	K2B/C
Samsung	K2C/C
Samsung	K2D/C
Samsung	K2E/C
Samsung	K2F/C
Samsung	K2G/C
Samsung	K2H/C
Samsung	K2J/C
Samsung	K2K/C
Samsung	K2L/C
Samsung	K2M/C
Samsung	K2N/C
Samsung	K2P/C
Samsung	K2R/C
Samsung	K2T/C
Samsung	K301A
Samsung	K301S
Samsung	K501A
Samsung	K501S
Samsung	K502A
Samsung	K503A
Samsung	KCJ01
Samsung	KT02

Samsung	E20
Samsung	E30
Samsung	E40
Samsung	X40
Samsung	F30GR
Samsung	F30RS

Conector 5.5*1.7mm(19V) -E

Acer	Acer2410
Acer	Acer3000
Acer	Acer310
Acer	Acer3200
Acer	Acer345
Acer	Acer4000
Acer	Acer4100
Acer	Acer4500
Acer	Acer600
Acer	AcerAspire1400Series
Acer	AcerAspire1410
Acer	AcerAspire1410Series
Acer	AcerAspire1411
Acer	AcerAspire1411WLMi
Acer	AcerAspire1412
Acer	AcerAspire1412LC
Acer	AcerAspire1412LCi
Acer	AcerAspire1412LM
Acer	AcerAspire1412LMi
Acer	AcerAspire1412WLMi
Acer	AcerAspire1413Acer
Acer	AcerAspire1413LM
Acer	AcerAspire1413LMi
Acer	AcerAspire1413WLMi
Acer	AcerAspire1414
Acer	AcerAspire1414L
Acer	AcerAspire1414LC
Acer	AcerAspire1414LM
Acer	AcerAspire1414LMi
Acer	AcerAspire1414WL
Acer	AcerAspire1414WLCi
Acer	AcerAspire1414WLMi
Acer	AcerAspire1415
Acer	AcerAspire1415LMi
Acer	AcerAspire1600Series
Acer	AcerAspire1640

Acer	AcerAspire1640Z
Acer	AcerAspire1650
Acer	AcerAspire1650Z
Acer	AcerAspire1680
Acer	AcerAspire2000
Acer	AcerAspire3000
Acer	AcerAspire3100
Acer	AcerAspire3100
Acer	AcerAspire3270
Acer	AcerAspire3610
Acer	AcerAspire3620
Acer	AcerAspire3640
Acer	AcerAspire3680
Acer	AcerAspire3690
Acer	AcerAspire3690
Acer	AcerAspire3810
Acer	AcerAspire4120
Acer	AcerAspire4220G
Acer	AcerAspire4310
Acer	AcerAspire4315
Acer	AcerAspire4320
Acer	AcerAspire4320G
Acer	AcerAspire4330
Acer	AcerAspire4520
Acer	AcerAspire4520
Acer	AcerAspire4520G
Acer	AcerAspire4530
Acer	AcerAspire4620
Acer	AcerAspire4710
Acer	AcerAspire4710G
Acer	AcerAspire4710ZG
Acer	AcerAspire4715
Acer	AcerAspire4715Z
Acer	AcerAspire4720
Acer	AcerAspire4720G
Acer	AcerAspire4730
Acer	AcerAspire4730ZG
Acer	AcerAspire4736
Acer	AcerAspire4745
Acer	AcerAspire4745G
Acer	AcerAspire4755
Acer	AcerAspire4810
Acer	AcerAspire4920
Acer	AcerAspire4920G

Acer	AcerAspire4930
Acer	AcerAspire4930G
Acer	AcerAspire4935
Acer	AcerAspire4936
Acer	AcerAspire4937
Acer	AcerAspire5000
Acer	AcerAspire5030
Acer	AcerAspire5050
Acer	AcerAspire5100
Acer	AcerAspire5110
Acer	AcerAspire5315
Acer	AcerAspire5510
Acer	AcerAspire5520G
Acer	AcerAspire5530G
Acer	AcerAspire5537
Acer	AcerAspire5550
Acer	AcerAspire5560
Acer	AcerAspire5570
Acer	AcerAspire5580
Acer	AcerAspire5590
Acer	AcerAspire5600
Acer	AcerAspire5610
Acer	AcerAspire5610Z
Acer	AcerAspire5620
Acer	AcerAspire5630
Acer	AcerAspire5650
Acer	AcerAspire5670
Acer	AcerAspire5680
Acer	AcerAspire5710G
Acer	AcerAspire5710ZG
Acer	AcerAspire5720G
Acer	AcerAspire5730ZG
Acer	AcerAspire5810
Acer	AcerAspire5910G
Acer	AcerAspire5920G
Acer	AcerAspire5930G
Acer	AcerAspire6920G
Acer	AcerAspire6930
Acer	AcerAspire6935
Acer	AcerAspire7000
Acer	AcerAspire7100
Acer	AcerAspire7110
Acer	AcerAspire7220
Acer	AcerAspire7520

Acer	AcerAspire7520G
Acer	AcerAspire7720
Acer	AcerAspire7720G
Acer	AcerAspire7730G
Acer	AcerAspire7730ZG
Acer	AcerAspire8920
Acer	AcerAspire8920G
Acer	AcerAspire8930
Acer	AcerAspire9100
Acer	AcerAspire9100
Acer	AcerAspire9110
Acer	AcerAspire9120
Acer	AcerAspire9300
Acer	AcerAspire9400
Acer	AcerAspire9410
Acer	AcerAspire9410Z
Acer	AcerAspire9420
Acer	AcerAspire9500
Acer	AcerAspire9510
Acer	AcerAspire9520
Acer	AcerAspireAS2420
Acer	AcerAspireE5
Acer	AcerAspireEX4630
Acer	AcerAspirem3
Acer	AcerAspirem5
Acer	AcerAspireONE531H
Acer	AcerAspireONE751
Acer	AcerAspireONED150
Acer	AcerAspireONED250
Acer	AcerAspireONED525
Acer	AcerAspireONED725
Acer	AcerAspireS3
Acer	AcerAspireS5
Acer	AcerAspireTM2420
Acer	AcerAspiretm3000
Acer	AcerAspirev3
Acer	AcerAspirev5
Acer	AcerAspirev7
Acer	AcerAspire3240
Acer	AcerAspire3250
Acer	AcerAspire3820
Acer	AcerAspire4310
Acer	AcerAspire4715
Acer	AcerAspire4738

Acer	AcerAspire4739
Acer	AcerAspire4741
Acer	AcerAspire4741G
Acer	AcerAspire4741Z
Acer	AcerAspire4741ZG
Acer	AcerAspire4743
Acer	AcerAspire4750
Acer	AcerAspire4810
Acer	AcerAspire4830TG
Acer	AcerAspire5030
Acer	AcerAspire5050
Acer	AcerAspire5517
Acer	AcerAspire5537
Acer	AcerAspire5540
Acer	AcerAspire5550
Acer	AcerAspire5738
Acer	AcerAspire5741
Acer	AcerExtensa4120
Acer	AcerExtensa4220
Acer	AcerExtensa4620
Acer	AcerExtensa4620Z
Acer	AcerExtensa5010
Acer	AcerExtensa5120
Acer	AcerExtensa5210
Acer	AcerExtensa5410
Acer	AcerExtensa5420
Acer	AcerExtensa5420G
Acer	AcerExtensa5610
Acer	AcerExtensa5620
Acer	AcerExtensa5620G
Acer	AcerExtensa5630G
Acer	AcerExtensa7620G
Acer	AcerExtensa7630G
Acer	AcerFerrariFR5000
Acer	AcerTravelMate207720
Acer	AcerTravelMate230
Acer	AcerTravelMate2300
Acer	AcerTravelMate2430
Acer	AcerTravelMate2440
Acer	AcerTravelMate2490
Acer	AcerTravelMate280
Acer	AcerTravelMate290
Acer	AcerTravelMate3000
Acer	AcerTravelMate3210

Acer	AcerTravelMate3280
Acer	AcerTravelMate3290
Acer	AcerTravelMate4000
Acer	AcerTravelMate4210
Acer	AcerTravelMate4220
Acer	AcerTravelMate4230
Acer	AcerTravelMate4260
Acer	AcerTravelMate4270
Acer	AcerTravelMate4280
Acer	AcerTravelMate4670
Acer	AcerTravelMate4730G
Acer	AcerTravelMate5110
Acer	AcerTravelMate5220G
Acer	AcerTravelMate5510
Acer	AcerTravelMate5520G
Acer	AcerTravelMate5530G
Acer	AcerTravelMate5610
Acer	AcerTravelMate5620
Acer	AcerTravelMate5710G
Acer	AcerTravelMate5720G
Acer	AcerTravelMate5730G
Acer	AcerTravelMate6410
Acer	AcerTravelMate6460
Acer	AcerTravelMate6500
Acer	AcerTravelMate6592G
Acer	AcerTravelMate7220
Acer	AcerTravelMate7220G
Acer	AcerTravelMate7510
Acer	AcerTravelMate7520
Acer	AcerTravelMate7520G
Acer	AcerTravelMate7530G
Acer	AcerTravelMate7720G
Acer	AcerTravelMate7720G
Acer	AcerTravelMate7730
Acer	AcerTravelMate7730G
Acer	AcerTravelMate7730G
Acer	AcerTravelMate7740
Acer	AcerTravelMate7740G
Acer	AcerTravelMate7740Z
Acer	AcerTravelMate7740ZG
Acer	AcerTravelMate7750
Acer	AcerTravelMate7750G
Acer	AcerTravelMate7750Z
Acer	AcerTravelMate7750ZG

Acer	AcerTravelMate8000
Acer	AcerTravelMate8100
Acer	AcerTravelMate8200
Acer	AcerTravelMate8210
Acer	AcerTravelMate8331
Acer	AcerTravelMate8371
Acer	AcerTravelMate8431
Acer	AcerTravelMate8471
Acer	AcerTravelMate8531
Acer	AcerTravelMate8571
Acer	AcerTravelMateC210
Acer	AcerTravelMateP253-MG
Acer	AcerTravelMateP273-MG
Acer	AcerTravelMateP453-MG
Acer	AcerTravelMateP653-MG
Acer	AcerTravelMateTimelineX8172
Acer	AcerTravelMateTimelineX8172T
Acer	AcerTravelMateTimelineX8172Z
Acer	AcerTravelMateTimelineX8200
Acer	AcerTravelMateTimelineX8210
Acer	AcerTravelMateTimelineX8331
Acer	AcerTravelMateTimelineX8331G
Acer	AcerTravelMateTimelineX8371
Acer	AcerTravelMateTimelineX8371G
Acer	AcerTravelMateTimelineX8372
Acer	AcerTravelMateTimelineX8372G
Acer	AcerTravelMateTimelineX8372T
Acer	AcerTravelMateTimelineX8372TG
Acer	AcerTravelMateTimelineX8372TZ
Acer	AcerTravelMateTimelineX8372Z
Acer	AcerTravelMateTimelineX8372ZG
Acer	AcerTravelMateTimelineX8472
Acer	AcerTravelMateTimelineX8472G
Acer	AcerTravelMateTimelineX8472T
Acer	AcerTravelMateTimelineX8472TG
Acer	AcerTravelMateTimelineX8472Z
Acer	AcerTravelMateTimelineX8473
Acer	AcerTravelMateTimelineX8473G
Acer	AcerTravelMateTimelineX8473T
Acer	AcerTravelMateTimelineX8473TG
Acer	AcerTravelMateTimelineX8481
Acer	AcerTravelMateTimelineX8481G
Acer	AcerTravelMateTimelineX8481T
Acer	AcerTravelMateTimelineX8481TG

Acer	AcerTravelMateTimelineX8572
Acer	AcerTravelMateTimelineX8572G
Acer	AcerTravelMateTimelineX8572T
Acer	AcerTravelMateTimelineX8572TG
Acer	AcerTravelMateTimelineX8573
Acer	AcerTravelMateTimelineX8573G
Acer	AcerTravelMateTimelineX8573T
Acer	AcerTravelMateTimelineX8573TG
Acer	AcerTravelMate2420
Acer	AcerTravelMate3240
Acer	AcerTravelMate4200
Acer	Aspire1413LC
Acer	GatewayMC7800
Acer	GatewayMC7801
Acer	GatewayMC-7801
Acer	GatewayMC7801u
Acer	GatewayMC-7801u
Acer	GatewayMC7803
Acer	GatewayMC-7803
Acer	GatewayMC7803u
Acer	GatewayMC-7803u

Conector 4.0*1.7mm(20V) - G

Lenovo	Lenovo110-14IBR
Lenovo	Lenovo110-15IBR
Lenovo	Lenovo320-141SK
Lenovo	Lenovo320-15IKB
Lenovo	Lenovo310-15IKB
Lenovo	LenovoIdeaPad100-15IBYN3540
Lenovo	LenovoIdeaPad100-14IBYN2840
Lenovo	Lenovo100-15IBY80MJN2940
Lenovo	LenovoIdeaPad80MJSeries
Lenovo	LenovoIdeaPad80MHSeries
Lenovo	LenovoIdeaPad100-15IBYN2840
Lenovo	LenovoIdeaPad100-14IBYN3540
Lenovo	LenovoIdeaPad10080MHN2940
Lenovo	LenovoIdeaPad10080MHN3540
Lenovo	LenovoIdeaPad100S80YNSeries
Lenovo	LenovoIdeaPad710s510s510710SeriesNotebook
Lenovo	LenovoN22N22-20TouchChromebook/Winbook, IdeaPad/ThinkPadN22
Lenovo	LenovoYOGA710510310SeriesLaptops
Lenovo	LenovoFlex4SeriesLaptops
Lenovo	LenovoIdeaPad100100S-14IBR (100s14"INCHESONLY!)
Lenovo	110110S310310S320320S510510S710710S720S-14IKB

Lenovo	110-15IBR
Lenovo	110-17ACL
Lenovo	110S-11IBR
Lenovo	320-15ABR
Lenovo	320-15IKB
Lenovo	320-17IKB
Lenovo	Lenovo100sN22N22-20TouchChromebook
Lenovo	N22Winbook
Lenovo	ThinkPadN22
Lenovo	IdeaPadN22
Lenovo	LenovoFlex4514"15"
Lenovo	113014351480147015701580
Lenovo	LenovoYoga510520710720-12IKB
Lenovo	LenovoMiix510,510-12IKB510-12ISK
Lenovo	LenovoFlex4-1435
Lenovo	LenovoFlex4-1470
Lenovo	LenovoFlex4-1480
Lenovo	LenovoFlex4-1570
Lenovo	LenovoFlex4-1580
Lenovo	LenovoIdeaPad100-15IBYN3540
Lenovo	LenovoIdeaPad100-14IBYN2840
Lenovo	LenovoIdeaPad100-15IBY80MJN2940
Lenovo	LenovoIdeaPad80MJSeries
Lenovo	LenovoIdeaPad80MHSeries
Lenovo	LenovoIdeaPad100-15IBYN2840
Lenovo	LenovoIdeaPad100-14IBYN3540
Lenovo	LenovoIdeaPad10080MHN2940
Lenovo	LenovoIdeaPad10080MHN3540
Lenovo	LenovoIdeaPad100S80YNSeries
Lenovo	LenovoIdeaPad100S-14IB
Lenovo	LenovoB50-10
Lenovo	LenovoYOGA510-14
Lenovo	LenovoYOGA310-14
Lenovo	LenovoYOGA710-13

Conector 5.5*3.0*10mm(19V) - H

Samsung	R700
Samsung	R730
Samsung	R780
Samsung	X60
Samsung	X65
Samsung	X330
Samsung	X331
Samsung	X430

Samsung	X431
Samsung	AD-4019
Samsung	ADP-40MH
Samsung	CPA-40-012A
Samsung	A04R005L
Samsung	Samsung ad-4019
Samsung	Samsung NC10
Samsung	Samsung NC20
Samsung	Samsung ND10
Samsung	Samsung ND20
Samsung	Samsung N110
Samsung	Samsung N120
Samsung	Samsung N130
Samsung	Samsung ND10 series
Samsung	Samsung ND20 series
Samsung	Samsung NC10 series
Samsung	Samsung NC20 series
Samsung	Samsung N110 series
Samsung	Samsung N120 series
Samsung	Samsung N130 series
Samsung	Samsung GS6
Samsung	Samsung Gt6
Samsung	Samsung Gt7
Samsung	Samsung Gt8
Samsung	X05 series
Samsung	VN
Samsung	GT
Samsung	NT
Samsung	SamsungA10 Series
Samsung	SamsungAD8019
Samsung	SamsungAD9019
Samsung	SamsungP Series
Samsung	SamsungP10 Series
Samsung	SamsungP20 NP20
Samsung	SamsungP25 Series
Samsung	SamsungP30 Series
Samsung	SamsungP35 NP25
Samsung	SamsungP40 Series
Samsung	SamsungSPA-V20
Samsung	SamsungT10 Series
Samsung	SamsungV20 Series
Samsung	SamsungV25 Series
Samsung	SamsungX20 Series
Samsung	SamsungX25 Series

Samsung	SamsungX50 Series
Samsung	Samsung V10
Samsung	SamsungV20
Samsung	SamsungV8095CX
Samsung	SamsungVM6000
Samsung	SamsungVM6300
Samsung	SamsungVM6300CT
Samsung	SamsungVM7000
Samsung	SamsungVM7500CT
Samsung	SamsungVM7550
Samsung	SamsungVM7550CT
Samsung	SamsungVM7600
Samsung	SamsungVM7600CT
Samsung	SamsungVM7600XT
Samsung	SamsungVM7650
Samsung	SamsungVM7650CT
Samsung	SamsungVM7650CXT
Samsung	SamsungVM7650CXTD
Samsung	SamsungVM7650XT
Samsung	SamsungVM7700
Samsung	SamsungVM7700XTD
Samsung	SamsungVM8000
Samsung	SamsungVM8080
Samsung	SamsungVM8080CT
Samsung	SamsungVM8080CXT
Samsung	SamsungVM8090
Samsung	SamsungVM8090CT
Samsung	SamsungVM8090CXTD
Samsung	SamsungVM8095
Samsung	SamsungVM8095CX
Samsung	SamsungVM8100
Samsung	SamsungVM8100CX
Samsung	SamsungVM8100CXTD
Samsung	SamsungVM8100KXTD
Samsung	SamsungVM8100XTD
Samsung	SamsungVM8110CXTD
Samsung	SamsungVM8110XTC
Samsung	SamsungWNBT21

Conector 4.5*3.0*10mm(19V) - O

HP	14-K031TX
HP	15-R015DX
HP	15-R018DX
HP	709985-002
HP	725G3

HP	ELITEX21011G1
HP	ELITEBOOK828G3
HP	ELITEBOOK840G5
HP	ELITEBOOKX360
HP	ENVY14
HP	G20
HP	M6-K022DX
HP	PAVILIONX360
HP	PAVILIONX36014-BA016NA
HP	PAVILIONX36014-BA036TX
HP	PAVILIONX36014-BA038TX
HP	PAVILIONX36014-BA042TX
HP	PAVILIONX36014-BA044TX
HP	PAVILIONX36014-BA049TX
HP	PAVILIONX36014-BA100NG
HP	PAVILIONX36014-BA102NG
HP	PAVILIONX36014-BA104TX
HP	PAVILIONX36014-BA108NG
HP	PAVILIONX36014-BA170NG
HP	ZBOOK15UG4
HP	ZHAN66AMD6MC34PC
HP	ZHAN66G2145TR04PC
HP	ZHAN66G2146MC32PC
HP	ZHAN66G2146ME24PC
HP	ZHAN66G2146SP53PC
HP	ZHAN66PROG2
HP	15-R011DX
HP	15-R017DX
HP	709985-001
HP	710412-001
HP	740G3
HP	ELITEBOOK1040G3
HP	ELITEBOOK830G5
HP	ELITEBOOK848G3
HP	ELITEBOOKX3601030G2
HP	ENVYTOUCHSMART
HP	HPENVYCOREI7
HP	M6-K025DX
HP	PAVILIONX36014-BA000
HP	PAVILIONX36014-BA033TX
HP	PAVILIONX36014-BA037TX
HP	PAVILIONX36014-BA039TX
HP	PAVILIONX36014-BA043TX
HP	PAVILIONX36014-BA046TX

HP	PAVILIONX36014-BA100
HP	PAVILIONX36014-BA100TX
HP	PAVILIONX36014-BA103NG
HP	PAVILIONX36014-BA105TX
HP	PAVILIONX36014-BA109NG
HP	PAVILIONX36014-BA170NZ
HP	ZHAN66AMD6HP15PC
HP	ZHAN66G214
HP	ZHAN66G2145TR12PC
HP	ZHAN66G2146MC35PC
HP	ZHAN66G2146MU54PC0
HP	ZHAN66PRO14G2
HP	ZHAN66G2
HP	15-F009WM
HP	15-F039WM
HP	15-F023WM
HP	15-F059WM

Conector 7.9 (20V) - K

Lenovo	G40
Lenovo	G400
Lenovo	G400S
Lenovo	G40-30
Lenovo	G40-45
Lenovo	G405
Lenovo	G405S
Lenovo	G40-70
Lenovo	G40-80
Lenovo	G50
Lenovo	G500
Lenovo	G500S22
Lenovo	G50-30
Lenovo	G50-45
Lenovo	G505
Lenovo	G50-50
Lenovo	G505S
Lenovo	G50-70
Lenovo	G50-80
Lenovo	G510
Lenovo	G70
Lenovo	G700
Lenovo	G70-50
Lenovo	G70-70
Lenovo	G70-80

Lenovo	G710
Lenovo	IdeapadB50-70
Lenovo	LenovoFlex14
Lenovo	LenovoFlex3-143-14703-1480
Lenovo	LenovoG400
Lenovo	LenovoG490
Lenovo	LenovoIdeaPadG400
Lenovo	LenovoIdeaPadG405G405s
Lenovo	LenovoIdeaPadG470
Lenovo	lenovoideapadS300
Lenovo	LenovoIdeaPadU330U330p
Lenovo	LenovoIdeaPadU430U430p
Lenovo	LenovoIdeaPadYoga1111sUltrabookSeries
Lenovo	LenovoIdeaPadYoga13
Lenovo	LenovoIdeaPadYoga2ProSeries
Lenovo	LenovoK2450
Lenovo	LenovoK4350
Lenovo	LenovoK4350A
Lenovo	LenovoK4450
Lenovo	LenovoS405
Lenovo	LenovoS410
Lenovo	LenovoS410P
Lenovo	LenovoS500
Lenovo	LenovoThinkPadEdgeE431
Lenovo	LenovoThinkPadEdgeE4316277AXU
Lenovo	LenovoThinkPadEdgeE4316277AYU
Lenovo	LenovoThinkPadEdgeE4316277AZU
Lenovo	LenovoThinkPadEdgeE4316277B2U
Lenovo	LenovoThinkPadEdgeE4316277B3U
Lenovo	LenovoThinkPadEdgeE4316277BTU
Lenovo	LenovoThinkPadEdgeE431SeriesUltrabook
Lenovo	LenovoThinkPadEdgeE440
Lenovo	LenovoThinkPadEdgeE455
Lenovo	LenovoThinkPadL440L450
Lenovo	LenovoThinkPadS1Yoga
Lenovo	LenovoThinkPadS1Yoga20CD
Lenovo	LenovoThinkPadS1Yoga20CD00BXUS
Lenovo	LenovoThinkPadS1Yoga20CD00BYUS
Lenovo	LenovoThinkPadS1Yoga20CD00CGUS
Lenovo	LenovoThinkPadS1YogaSeriesUltrabook
Lenovo	LenovoThinkPadS3Yoga14
Lenovo	LenovoThinkPadS431
Lenovo	LenovoThinkPadT431T431s
Lenovo	LenovoThinkPadT440T440pT440s

Lenovo	LenovoThinkPadT450T450s
Lenovo	LenovoThinkpadX300S
Lenovo	LenovoThinkpadE431
Lenovo	LenovoThinkpadE531
Lenovo	LenovoThinkpadL440
Lenovo	LenovoThinkpadL540
Lenovo	LenovoThinkpadS230U
Lenovo	LenovoThinkpadS3
Lenovo	LenovoThinkpadS5
Lenovo	LenovoThinkpadT430
Lenovo	LenovoThinkpadT440
Lenovo	LenovoThinkpadT440P
Lenovo	LenovoThinkpadT440S
Lenovo	LenovoThinkpadT540P
Lenovo	LenovoThinkpadX230S
Lenovo	LenovoThinkpadX240
Lenovo	LenovoThinkpadX240S
Lenovo	LenovoThinkpadX301S
Lenovo	LenovoV4400U
Lenovo	LenovoYoga11S
Lenovo	LenovoYoga13
Lenovo	LenovoYoga2
Lenovo	LenovoYoga300
Lenovo	LenovoYoga500
Lenovo	LenovoZ410
Lenovo	LenovoZ505
Lenovo	LenovoZ510
Lenovo	LenovoZ580
Lenovo	LenovoZ710

Conector 5.5*2.5mm(19V) - C

Acer	AcerAspire1200
Acer	AcerAspire1680
Acer	AcerAspire1360
Acer	AcerAspire1500
Acer	AcerAspire1520
Acer	AcerAspire1600
Acer	AcerAspire1610
Acer	AcerAspire1620
Acer	AcerAspire1660
Acer	AcerAspire1670
Acer	AcerAspire2010
Acer	AcerAspire2020
Acer	AcerTravelmateTn291LCI

Acer	AcerTravelmateTM301XCI
Acer	AcerTravelmateTM291LMI
Acer	AcerTravelMate8000
Acer	AcerTravelMate739TLV
Acer	AcerTravelMate738TLU
Acer	AcerTravelMate734TL
Acer	AcerTravelMate732TX
Acer	AcerTravelMate730TX
Acer	AcerTravelMate720
Acer	AcerTravelMate660
Acer	AcerTravelMate613TXV
Acer	AcerTravelMate613TXC
Acer	AcerTravelMate612TXV
Acer	AcerTravelMate612TXC
Acer	AcerTravelMate611TXV
Acer	AcerTravelMate611TXC
Acer	AcerTravelMate610TXVi
Acer	AcerTravelMate610TXV
Acer	AcerTravelMate610TXC
Acer	AcerTravelMate610
Acer	AcerTravelMate604TER
Acer	AcerTravelMate603TER
Acer	AcerTravelMate603
Acer	AcerTravelMate602TER
Acer	AcerTravelMate602
Acer	AcerTravelMate600TER
Acer	AcerTravelMate6000
Acer	AcerTravelMate600
Acer	AcerTravelMate551XV
Acer	AcerTravelMate529TXV
Acer	AcerTravelMate528TE
Acer	AcerTravelMate525TXV
Acer	AcerTravelMate525
Acer	AcerTravelMate524TXV
Acer	AcerTravelMate522
Acer	AcerTravelMate521TXV
Acer	AcerTravelMate521TE
Acer	AcerTravelMate521T
Acer	AcerTravelMate520
Acer	AcerTravelMate506DX
Acer	AcerTravelMate506
Acer	AcerTravelMate500
Acer	AcerTravelMate4500
Acer	AcerTravelMate4000

Acer	AcerTravelMate354TEV
Acer	AcerTravelMate354TE
Acer	AcerTravelMate353TEV
Acer	AcerTravelMate353TE
Acer	AcerTravelMate352TE-n
Acer	AcerTravelMate352TE
Acer	AcerTravelMate351TE
Acer	AcerTravelMate350TE
Acer	AcerTravelMate347T
Acer	AcerTravelMate345T
Acer	AcerTravelMate342
Acer	AcerTravelMate341T
Acer	AcerTravelMate340T
Acer	AcerTravelMate330T
Acer	AcerTravelMate3200
Acer	AcerTravelMate3000
Acer	AcerTravelMate290E
Acer	AcerTravelMate290
Acer	AcerTravelMate270xv
Acer	AcerTravelMate2700
Acer	AcerTravelMate270
Acer	AcerTravelMate2600
Acer	AcerTravelMate260
Acer	AcerTravelMate250PE
Acer	AcerTravelMate2500
Acer	AcerTravelMate250
Acer	AcerTravelMate240
Acer	AcerTravelMate2300
Acer	AcerTravelMate225XV-Pro
Acer	AcerTravelMate225XC
Acer	AcerTravelMate225X
Acer	AcerTravelMate223XC
Acer	AcerTravelMate223X
Acer	AcerTravelMate2203
Acer	AcerTravelMate2200
Acer	AcerTravelMate220
Acer	AcerTravelMate213TXV
Acer	AcerTravelMate213TX
Acer	AcerTravelMate213T
Acer	AcerTravelMate212TXV
Acer	AcerTravelMate212TE
Acer	AcerTravelMate212T
Acer	AcerTravelMate210TER
Acer	AcerTravelMate210T

Acer	AcerTravelMate210
Acer	AcerTravelMate2100
Acer	AcerTravelMate2000
Acer	AcerTravelmateTM252PE
Acer	AcerTravelmateC110
Acer	AcerTravelMate735TLV
Acer	AcerTravelMate600TER
Acer	AcerTravelMate527TXV
Acer	AcerTravelMate525TE
Acer	AcerTravelMate330
Acer	AcerTravelMate240
Acer	AcerTravelMate2203LMI
Acer	AcerTravelMate211T
Acer	Ferrari3000
Acer	Ferrari3000LMI
Acer	AcerExtensa365
Acer	AcerExtensa366D
Acer	AcerExtensa367D
Acer	AcerExtensa368D
Acer	AcerExtensa390
Acer	AcerExtensa390C
Acer	AcerExtensa390CX
Acer	AcerExtensa393
Acer	AcerExtensa900
Acer	ACERExtensaESS3-391T
Acer	Aspire1710
Acer	AspireAS2003LMi
Acer	AspireTM240
Acer	AspireTM250
Acer	AcerAcerNote367DSeries
Acer	AcerAcerNote367TSeries
Acer	AcerAcerNote390Series
Acer	AcerAcerNote390ASeries
Acer	AcerAcerNote395Series
Acer	AcerAcerNote391Series
Acer	AcerAcerNote392Series
Acer	AcerAcerNote393Series
Acer	AcerAcerNote394Series
Acer	AcerAnywhere1100LXSeries
Acer	AcerAnywhere1120LXSeries
Dell	DellInspiron3000
Dell	DellInspiron3200
Dell	DellInspiron3500
Asus	A1

Asus	A3
Asus	L1
Asus	L7
Asus	L8
Asus	M1
Asus	M2A
Asus	M5N
Asus	M8
Asus	S1
Asus	S2A/B
Asus	S3
Asus	S5N/Ne
Asus	S8
Asus	T9
Asus	Z2series
Asus	Elite7200
Asus	Elite73
Asus	EliteL7200
Asus	EliteL7200B
Asus	EliteL8400
Asus	EliteL8400
Asus	EliteS8200
Asus	EliteS8600
Asus	F2F/Hf
Asus	A6V/R/U/F/Jc
Asus	F3F
Asus	A8F/H
Asus	A9
Asus	M9
Asus	M6
Asus	V6/VX1
Asus	W3V/A/Z
Asus	W5
Asus	W6F
Asus	Z35H/L
Asus	W7F
Asus	U5
Asus	S6
Asus	R1
Compaq	298239-001
Compaq	177624-001
Compaq	177626-001
Compaq	180676-001
Compaq	198713-001

Compaq	208190-001
Compaq	222113-001
Compaq	298237001
Compaq	LE-9702A
Compaq	180675-001
Compaq	198714-001
Compaq	ADP-60BB
Compaq	API-7595
Compaq	ADP-9510-19A
Compaq	ADP-45TB
Compaq	CQPS1200
Compaq	ADP-60DB
Compaq	API-7269
Delta	A1
Delta	L8
Delta	M5N
Delta	S2A
Delta	B
Delta	N
Delta	S3
Delta	T9
Delta	L1
Delta	M1
Delta	M8
Delta	S5N/Ne
Delta	Z2series
Delta	L7
Delta	M2A
Delta	S1
Delta	S8
Delta	210TER211T212T
Delta	212TE212TXV213T
Delta	3004WLM35003610
Delta	20033004LCI3004LMI
Delta	233XC260270
Delta	270XV280290
Delta	223X223XC225X
Delta	301XCI330330T
Delta	225XC225XV230
Delta	213TX213TXV220
Delta	290E291LCI291LMI
Delta	340T341T342
Delta	345T347T350
Delta	525TXV528TE

Delta	354TE354TEV360
Delta	521TE524TXV525TE
Delta	350TE351TEV352TE
Delta	DF988A
Delta	DF989A
Delta	DF990A
Delta	DF992A
Delta	DF993A
Delta	DF994A
Delta	DG194A
Delta	DG195A
Delta	DG196A
Delta	DG200A
Delta	DG201A
Delta	DG202A
Delta	DG203A
Delta	DG220T
Delta	DG221T
Delta	DG222T
Delta	zd7012EA
Delta	Aspire1710
Delta	Ferrari3000
Delta	TM240ZD7000
Delta	Ferrari3000LMI
Delta	DR089UDR768E
Delta	DR340UDP764E
Delta	DM788ADM788A
Delta	DP769EDT859U
Delta	DM790ADP768E
Delta	DR761EDR762E
Delta	AspireAS2003LMi
Delta	DP353EDN730AV
Delta	DP763EDM793AR
Delta	DM793ADP448UR
Delta	DP448UDR089UR
Delta	DP765EDM790AR
Delta	TM252PETM291LCI
Delta	TM291LMITM301XCI
Delta	A60-S156
Delta	A60-S1561
Delta	A60-S166
Delta	A60-S1661
Delta	A60-S1662
Delta	A65-S1063

Delta	A65-S1064
Delta	A65-S1065
Delta	A65-S1066
Delta	A60-S1591ST
Delta	A65-S1067
Delta	A65-S1068
Delta	A65-S1069
Delta	A65-S1070
Delta	A65-S109
Delta	A75-2061
Delta	A75-S206
Delta	A75-S2091
Delta	A75-S211
Delta	A75-S2111
Delta	A75-S2112
Delta	A75-S226
Delta	A75-S2261
Delta	A75-S229
Delta	DR770EDP761E
Delta	DP762EDP767E
Delta	DP770EDM791AR
Delta	DM791ADP766E
Delta	DP447UDP446U
Delta	DR769E3005US
Delta	3008CL3015CA
Delta	3015US3017CL
Delta	3019CL3020US
Gateway	GatewaySolo2000
Gateway	GatewaySolo2150
Gateway	GatewaySolo2500
Gateway	GatewaySolo2500SE
Gateway	GatewaySolo2500LS
Gateway	GatewaySolo9150
Gateway	GatewaySolo1100
Gateway	GatewaySolo2100
Gateway	GatewaySolo2200
Gateway	GatewaySolo2300
Gateway	GatewaySolo9100
Gateway	GatewaySolo5100
Gateway	GatewaySolo2550
Gateway	GatewaySolo5300
Gateway	GatewaySolo9300
Gateway	GatewaySolo9500
Gateway	GatewaySolo9550

Gateway	GatewaySolo9000Series
Gateway	GatewaySolo3000Series
Gateway	GatewaySolo5000Series
Gateway	GatewaySolo5150
Gateway	GatewaySolo1000Series
Gateway	GatewaySolo2000Series
Gateway	GatewayNX500Series
Gateway	GatewayNXSeries
Gateway	GatewayML3000Series
Gateway	GatewayMXSeries
Gateway	GatewayNX200Series
Gateway	GatewayMT6800Series
Gateway	GatewayMT6700Series
Gateway	GatewayTabletPC
Gateway	Gateway3000Series
Gateway	Gateway4000Series
Gateway	Gateway6000Series
Gateway	GatewayCXSeries
Gateway	GatewayMSeries
Gateway	GatewayMT3000Series
Gateway	S-7200
Gateway	S-7200C
Gateway	CX200XSeries
Gateway	S7200Series
Gateway	CX200S
Gateway	CX200
HP	298239-001
HP	180676-001
HP	177626-001
HP	198713-001
HP	222113-001
HP	AC-C10
HP	CQPS1200
HP	261867-001
HP	325112-001
HP	325112-011
HP	325112-061
HP	325112-081
HP	325112-111
HP	325112-201
HP	325112-291
HP	325112-AA1
HP	325112-AD1
HP	325112-BB1

HP	382021-002
HP	384021-001
HP	391173-001
HP	416421-001
HP	463955-001
HP	609940-001
HP	HP Omnibook Series
HP	HP Omnibook Series XE2
HP	HP Omnibook Series XE3
HP	HP Omnibook Series 500
HP	HP Omnibook Series 900
HP	HP Omnibook Series 4100
HP	HP Omnibook Series 4150
HP	HP Omnibook Series 6000
HP	HP Omnibook Series 7100
HP	HP Omnibook Series 7150
HP	HP Omnibook Series 2100
HP	HP Omnibook Series 3000
HP	HP Omnibook Series 3100
HP	HP Pavilion Series N3150
HP	HP Pavilion Series N3250
HP	HP Pavilion Series N3270
HP	HP Pavilion Series N3290/5
HP	HP Pavilion Series N3310
HP	HP Pavilion Series N3330
HP	HP Pavilion Series N3390
HP	HP Pavilion Series N3410
HP	HP Pavilion Series N5000
HP	HP Pavilion Series N5100
HP	HP Pavilion Series N5125
HP	HP Pavilion Series N5130
HP	HP Pavilion Series N5150
HP	HP Pavilion Series N5170
HP	HP Pavilion Series N5190/5
HP	HP Pavilion Series N5200
HP	ZV5000
HP	ZV5000T
HP	ZV5000Z
HP	ZV5100
HP	ZV5103
HP	ZV5001US
HP	ZV5001US
HP	ZV5001US
HP	ZV5002US

HP	ZV5030CA
HP	ZV5030CA
HP	ZV5030US
HP	ZV5030US
HP	ZV5034US
HP	ZV5034US
HP	ZV5037WM
HP	ZV5101US
HP	PC898U
HP	PC896U
HP	ZV5105US
HP	ZV5120CA
HP	ZV5120US
HP	PC897U
HP	ZV5160CA
HP	ZV5160US
HP	ZV5200
HP	ZV5201
HP	ZV5220US
IBM	ThinkPad i1400
IBM	ThinkPad i1442
IBM	ThinkPadi1460
IBM	ThinkPadi1480
IBM	ThinkPadi1482
IBM	ThinkPadi1500
IBM	ThinkPadi1522
IBM	ThinkPadi1700
IBM	ThinkPadi1720
Fujitsu	FujitsuLifeBookA4170Series
Fujitsu	FujitsuLifeBookA4177Series
Fujitsu	FujitsuLifeBookA4178Series
Fujitsu	FujitsuLifeBookA4187Series
Fujitsu	FujitsuLifeBookA4190Series
Fujitsu	FMV-AC332A
Fujitsu	ADP-65Y-A
Fujitsu	PC-AP8200
Fujitsu	SADP-65KB
Fujitsu	PCF-AP6530
Fujitsu	PCF-AP6510
Fujitsu	PC-AP7400
Toshiba	DynaBookSS425Series
Toshiba	Satellite1000
Toshiba	SatelliteZ2
Toshiba	Satellite1005

Toshiba	Satellite1005S101
Toshiba	Satellite1200
Toshiba	SatelliteS252
Toshiba	Satellite1600
Toshiba	Satellite1605CDS
Toshiba	Satellite1620CDS
Toshiba	Satellite1625CDT
Toshiba	Satellite1640CDT
Toshiba	Satellite1670CDS
Toshiba	Satellite1675CDS
Toshiba	Satellite1690CDT
Toshiba	SatelliteA100-155
Toshiba	SatelliteA100-158
Toshiba	SatelliteA100-159
Toshiba	SatelliteA100-161
Toshiba	SatelliteA100-165
Toshiba	SatelliteA100-166
Toshiba	SatelliteA100-168
Toshiba	SatelliteA100-169
Toshiba	SatelliteA100-170
Toshiba	SatelliteA100-175
Toshiba	SatelliteA100-181
Toshiba	SatelliteA100-188
Toshiba	SatelliteA100-192
Toshiba	SatelliteA100-193
Toshiba	SatelliteA100-209
Toshiba	SatelliteA100-212
Toshiba	SatelliteA100-218
Toshiba	SatelliteA100-220
Toshiba	SatelliteA100-232
Toshiba	SatelliteA100-233
Toshiba	SatelliteA100-270
Toshiba	SatelliteA100-500
Toshiba	SatelliteA100-507
Toshiba	SatelliteA100-508
Toshiba	SatelliteA100-510
Toshiba	SatelliteA100-521
Toshiba	SatelliteA100-522
Toshiba	SatelliteA100-523
Toshiba	SatelliteA100-525
Toshiba	SatelliteA100-528
Toshiba	SatelliteA100-529
Toshiba	SatelliteA100-533
Toshiba	SatelliteA100-534

Toshiba	SatelliteA100-551
Toshiba	SatelliteA100-JH2
Toshiba	SatelliteA100-LE1
Toshiba	SatelliteA100-LE4
Toshiba	SatelliteA100-237
Toshiba	SatelliteA100-250
Toshiba	SatelliteA100-269
Toshiba	SatelliteA100-253
Toshiba	SatelliteM40X-105
Toshiba	SatelliteM40X-112
Toshiba	SatelliteM40X-115
Toshiba	SatelliteM40X-119
Toshiba	SatelliteM40X-129
Toshiba	SatelliteM40X-142
Toshiba	SatelliteM40X-159
Toshiba	SatelliteM40X-161
Toshiba	SatelliteM40X-163
Toshiba	SatelliteM40X-166
Toshiba	SatelliteM40X-168
Toshiba	SatelliteM40X-169
Toshiba	SatelliteM40X-175
Toshiba	SatelliteM40X-183
Toshiba	SatelliteM40X-184
Toshiba	SatelliteM40X-231
Toshiba	SatelliteM40X-250
Toshiba	SatelliteM40X-251
Toshiba	Satellite1695CDT
Toshiba	Satellite1700
Toshiba	Satellite1715XCDS
Toshiba	Satellite1730
Toshiba	Satellite1730CDT
Toshiba	Satellite1735XCDS
Toshiba	Satellite1755
Toshiba	Satellite1755CDT
Toshiba	Satellite1755CE
Toshiba	Satellite1755DVD
Toshiba	Satellite3000
Toshiba	Satellite3000S
Toshiba	SatelliteS353
Toshiba	A100-163
Toshiba	A100-259
Toshiba	A100-295
Toshiba	A100-570
Toshiba	A100-649

Toshiba	A100-S2211
Toshiba	A110-10
Toshiba	A110-177
Toshiba	A110-178
Toshiba	A110-203
Toshiba	A110-260
Toshiba	A110-289
Toshiba	A110-339
Toshiba	A110-370
Toshiba	A200-1BP
Toshiba	A200-10X
Toshiba	A200-10Z
Toshiba	A200-11C
Toshiba	A200-12F
Toshiba	A200-13L
Toshiba	A200-13O
Toshiba	A200-13R
Toshiba	A200-13T
Toshiba	A200-13U
Toshiba	A200-1AE
Toshiba	A200-14D
Toshiba	A200-14E
Toshiba	A200-180
Toshiba	A200-18T
Toshiba	A200-19I
Toshiba	A200-19K
Toshiba	A200-19M
Toshiba	A200-1A9
Toshiba	A200-1AA
Toshiba	A200-1AB
Toshiba	A200-1Ai
Toshiba	A105-S1014
Toshiba	A105-S101X
Toshiba	A105-S171
Toshiba	A105-S1712
Toshiba	A105-S171X
Toshiba	A105-S2001
Toshiba	A105-S2011
Toshiba	A105-S2021
Toshiba	A105-S2031
Toshiba	A105-S2051
Toshiba	A105-S2061
Toshiba	A105-S2071
Toshiba	A105-S2081

Toshiba	A105-S2091
Toshiba	A105-S2101
Toshiba	A105-S2111
Toshiba	A105-S2121
Toshiba	A105-S2131
Toshiba	A105-S2141
Toshiba	A105-S2194
Toshiba	A105-S2201
Toshiba	A105-S2204
Toshiba	A105-S2231
Toshiba	A105-S2236
Toshiba	A105-S271
Toshiba	A105-S2712
Toshiba	A105-S101
Toshiba	A105-S1012
Toshiba	A105-S1013
Toshiba	A135-S2306
Toshiba	A135-S2326
Toshiba	A135-S2386
Toshiba	A135-S2396
Toshiba	A135-S4407
Toshiba	A135-S4417
Toshiba	A135-S4427
Toshiba	A135-S4437
Toshiba	A135-S4447
Toshiba	A135-S4457
Toshiba	A135-S2246
Toshiba	A135-S2256
Toshiba	A135-S2266
Toshiba	A135-S2276
Toshiba	A135-S2346
Toshiba	A135-S2356
Toshiba	A135-S2376
Toshiba	A135-S2286
Toshiba	A135-S2296
Toshiba	L35-S2151
Toshiba	L35-S2161
Toshiba	L35-S2171
Toshiba	L35-S2174
Toshiba	L35-S2194
Toshiba	L35-S1054
Toshiba	L35-S2316
Toshiba	PA3165U-1ACA
Toshiba	PA5035U-1ACA

Toshiba	APA5180U-1ACA
NEC	PA2409U
NEC	PA2411
NEC	PA2411U
NEC	PA2426U
NEC	PA2438
NEC	PA2438U
NEC	PA2440
NEC	PA2440U
NEC	PA2444
NEC	PA2444U
NEC	PA2444UE
NEC	PA3049U
NEC	PA3049U-1ACA
NEC	PA3080
NEC	PA3080E
NEC	PA3080E-1ACA
NEC	PA3080U
NEC	PA3080U-1ACA
NEC	PA3084PA3084U
NEC	PA3084U-1ACA
NEC	PA3153
NEC	PA3153E
NEC	PA3153E-1ACA
NEC	PA3153E-1ACAB
NEC	PA3153U
NEC	PA3153U-1ACA
NEC	PA3201
NEC	PA3201U
NEC	PA3201U-1ACA
NEC	PA3241
NEC	PA3241E
NEC	PA3241E-1ACA
NEC	PA3241E-1ACAB
NEC	PA3241E-2ACA
NEC	PA3241U
NEC	PA3241U-1ACA
NEC	PA3241U-2ACA
NEC	PA3260E
NEC	PA3260E-1ACA
NEC	PA3260U
NEC	PA3260U-1ACA
NEC	PA3282
NEC	PA3282E

NEC	PA3282E-1ACA
NEC	PA3282E-2ACA
NEC	PA3282U
NEC	PA3282U-1ACA
NEC	PA3282U-2ACA
NEC	PA5251U
NEC	PA5251UA
NEC	PA3377E-2ACA
NEC	NECVersa2400
NEC	NECVersa2400CD
NEC	NECVersa2405
NEC	NECVersa2405CD
NEC	NECVersa2430
NEC	NECVersa2430CD
NEC	NECVersa2435C
NEC	NECVersa2435CD
NEC	NECVersa2500
Liteon	PA-1900-05
Liteon	PA-1900-24

Conector 5.5*2.1mm(19V) - D2

Acer	AcerAcerNote330T
Acer	AcerAspire1200
Acer	AcerAspireE5-573G
Acer	AcerTravelMate210
Acer	AcerTravelMate220
Acer	AcerTravelMate223X
Acer	AcerTravelMate223XC
Acer	AcerTravelMate225X
Acer	AcerTravelMate225XC
Acer	AcerTravelMate225XV-Pro
Acer	AcerTravelMate230
Acer	AcerTravelMate233XC
Acer	AcerTravelMate240
Acer	AcerTravelMate260
Acer	AcerTravelMate270
Acer	AcerTravelMate270xv
Acer	AcerTravelMate280
Acer	AcerTravelMate290
Acer	AcerTravelMate330
Acer	AcerTravelMate330T
Acer	AcerTravelMate340T
Acer	AcerTravelMate350
Acer	AcerTravelMate351TEV
Acer	AcerTravelMate360

Acer	AcerTravelMate500
Acer	AcerTravelMate506
Acer	AcerTravelMate506DX
Acer	AcerTravelMate520
Acer	AcerTravelMate521T
Acer	AcerTravelMate521TE
Acer	AcerTravelMate521TXV
Acer	AcerTravelMate522
Acer	AcerTravelMate525
Acer	AcerTravelMate525TXV
Acer	AcerTravelMate527TXV
Acer	AcerTravelMate529TXV
Acer	AcerTravelMate530
Acer	AcerTravelMate551
Acer	AcerTravelMate600
Acer	AcerTravelMate600TER
Acer	AcerTravelMate602
Acer	AcerTravelMate602TER
Acer	AcerTravelMate603
Acer	AcerTravelMate610
Acer	AcerTravelMate620
Acer	AcerTravelMate630
Acer	AcerTravelMate730
Acer	AcerTravelMate730TXV
Acer	AcerTravelMate732
Acer	AcerTravelMate732TLV
Acer	AcerTravelMate735TLV
Acer	AcerTravelMate735TXV
Acer	AcerTravelMate738TLV
Acer	AcerTravelMate739TLV
Acer	AcerTravelMate740
Acer	AcerTravelMatea550
Acer	AcerTravelMatea551
Acer	AcerTravelMateAlpha550
Acer	AcerTravelMate210T
Acer	AcerTravelMate210TER
Acer	AcerTravelMate212T
Acer	AcerTravelMate212TE
Acer	AcerTravelMate212TXV
Acer	AcerTravelMate213T
Acer	AcerTravelMate213TXV
Acer	E1-470P
Acer	E1-472G
Acer	E1-522E-521

Acer	E1-531
Acer	E1-532P
Acer	E1-572
Acer	GatewayNC55C